POLYMERS ERO TEX

DAN SALSINGER CPESC

EROQIE

What polymers can do:

- >Storm water clarification- sediment control
- ➤ Soil stabilization- erosion control
- ➤ Soil thickening- construction activity aide

ERO () TEX

Why Polymers?

Because by themselves, mechanical practices (silt fences, blankets, sediment basins, ect.) do not adequately control erosion and sedimentation...

- > leaving construction site water discharges turbid
- > costing owners and contractors money, grading rework, and structural damage.

EROÔTEX

POLYMERS

- The generic name for these products is PAM (polyacrylamide)
- Typically used in conjunction with other management practices.
- Relevant information pertaining to PAM use for erosion and sediment control can be

found at: http://kimberly.ars.usda.gov/pampage.shtml http://kimberly.ars.usda.gov/pamprim.shtml www.dcr.state.va.us/swdoc/anionic.pdf www.siltstop.com www.priceandcompany.com

- Relevant information on these web sites answers all questions about:

 Plant, Human and wildlife toxicity

 - Bioaccumulation within plant or soil structures
 Polymer residue
 Handling precautions

ERO OTEX

Three steps are needed for performance:

- 1. Proper polymer selection
- 2. Proper use & introduction
- 3. Mixing of polymer

ERO () TEX

Polymer Types:

- Emulsion
- Granulated
- Gel block



ERO OTEX

What needs to be maintained? • Floc logs need to be checked often • Clean out floc pits • Clean and recharge baffle panels • Redo any hydro mulched areas that have been disturbed • Redo areas when needed for temporary shut down • Apply again after 2-3 months (temp. stab.)

• Is the water cleaner?